

EXCEL

Takasago Rim

TWS-206AN Torque Wrench

The Excel Torque Wrench is a precision instrument. Keep it stored in the protective plastic case when not in use to protect it from damage, dirt, and moisture.

General recommendation for most motocross & off-road wheels is 45-50 Lb.in or 5.1-5.6 N.m. Consult your service manual for exact settings. NOTE: Always reset dial to zero before wrench is placed in storage box.

Warning

1. A torque wrench is designed to set final spoke nipple tension. DO NOT use it to loosen nipples or to disassemble wheels. Use a standard nipple wrench for those jobs.
2. Do not turn the small set screw at the bottom of the wrench. This will affect the calibration factor.

It is assumed that the purchaser of this tool understands how to use a torque wrench correctly and has experience building motorcycle wheels. If that is not the case, please see our website or contact us for complete instructions. www.excel-rim.co.jp/global/

Newton Meters	Inch Pounds	Kilogram Meters
N.m.	Lb.in	Kg.m
3.4	30.1	.35
3.6	31.9	.37
3.8	33.6	.39
4.0	35.4	.41
4.2	37.2	.43
4.4	38.9	.45
4.6	40.7	.47
4.8	42.5	.49
5.0	44.3	.51
5.2	46.0	.53
5.4	47.8	.55
5.6	49.6	.57
5.8	51.3	.59
6.0	53.1	.61
6.2	54.9	.63
6.4	56.6	.65
6.6	58.4	.67
6.8	60.2	.69

Thank you for choosing EXCEL

EXCEL RIM Co., Ltd.

www.excel-rim.co.jp/global/